



IMPORTANT PACKING INSTRUCTIONS REGARDING YOUR GEOCHRON

1. Set Geochron to February 9th; Lock the Mechanism Screws
Located on the back, bottom middle section of the Geochron.
2. Set the Geochron to March 21 (After the Mechanism is
Locked)
3. Roll Up the Electrical Cord, Tape to the Bottom of the Unit
4. Tape an "X" Across the Glass with Painter's Tape
5. Place Unit in a Plastic Bag
6. Attach and Secure Styrofoam Corners as Showed in Figure 1
7. Seal One End of the Box With Packing Tape (Figure 2)
8. Slide Geochron Into Inner Box and Seal Open End With
Packing Tape (Figure 2)
9. Attach Foam Corner Blocks to Inner Box (Fig. 2) and Slide into
Outer Box (Fig. 3)
10. Insert 2 Additional Foam Corner Blocks
11. Seal Remaining Open End of Outer Box (Fig. 3)
12. Complete Return Authorization Form
13. Insure Unit for No Less Than \$700.00

Note: Refer to Diagram Sheet for Detailed Packing Instructions